

# Solve™

## INSTALLER CHECKLIST

Everything you need for a Solve Mount installation

### ESSENTIAL TOOLS



**28mm Diamond  
Coring Bit**



**7mm Wood Auger  
Drill Bit**  
Bosch PRO



**Solve Drill Guide**  
1 per box included



**7mm Hex Socket**  
For drill driver



**Battery Drill  
Driver**  
High speed, NO hammer



**Tape Measure**



**Rafter Finder**  
Or alternative



**Chalk Marker**  
Or similar



**2 x 15mm  
Spanners**



**1 x 17mm  
Spanner**



**Builders Square**

### PROHIBITED TOOLS

- Non-diamond coring bit
- Blunt coring bit
- Over / under sized coring bit
- Hammer action drill — never use hammer action on tile or timber
- Impact driver

### CONSUMABLES



**Metal Free Anti-Seize Grease**

e.g. Molykote 1000 or Loctite LB 8009

### Before You Start

Ensure your battery drill driver is set to HIGH SPEED mode with NO hammer action. Check your coring bit is undamaged before each install. Always use the Solve Drill Guide for accurate positioning, the helps the seal enter the hole without getting caught, ensuring even expansion.